

# Platform scale KERN ILT

PREMIUM



KERN ILT-BM



KERN ILT-BM



KERN ILT-NM



KERN ILT-GM

State-of-the-art premium touchscreen platform scale with the complete range of functions for demanding processes

**Backlit and touch-sensitive LCD display** with digit height 21 mm, screen diagonal 5,7" (approx. 145 mm), WxH 115x86 mm. Dimensions of display device WxDxH 215x156x71 mm. Thanks to the interactive touch display, the menu and processes are self-explanatory. This reduces training times, avoids operating errors and like this, ensures a more efficient functionality

**Intuitive operation, increases efficiency and saves costs:** Easy capture of item data at the PC, call up of items on the scale using the connected barcode or RFID scanner, output of weighing data using the large or second display or control outputs, data transfer to the PC, printer or alibi memory.

**User-friendly piece-counting function:** entry and call up of items to be counted from the database with all relevant additional data such as piece weight, name, price (for internal valuation), reference quantity, tare container weight, barcode, item image etc. Also integrated: automatic reference optimisation, correction of reference weights, freely selectable reference quantity and much more  
Note: on the basis of the KERN ILT range, you can entry and call up of a wide range of high-performance counting systems - your KERN product specialist will be pleased to assist you

11



### High level of connectivity

- 1 x Ethernet interface
- 2 x RS-232 interface
- 2 x USB interface, e.g. for data exchange or connection of barcode or RFID scanners for quick call up of stored items
- Digital I/O interface (4 in / 4 out) e.g. for machine and plant control
- 1 x Interface for additional display



**Identification by RFID:** rapid and secure identification of users, items, vehicles, etc. using the optional RFID transponder card reader. The data can be read and edited (suitable for ILT-BM, -GM, KET-TM)



**Possible record of items using the optional barcode scanner,** see accessory. Ideal for rapid recording of items, e.g. as part of stocktaking or to record recipe ingredients during recipe weighing etc.

# Platform scale KERN ILT

## Features

- **Convenient recipe-weighing:** complete recipes with all recipe ingredients and associated target values, names, tolerances, tare weights etc. can be stored. If there is an excess amount of one ingredient the practical back calculation function automatically calculates the new target weights of the other ingredients
- **Multiplier function:** recipes and their ingredients can be multiplied at will at the press of a button, which is ideal for the production of larger containers, bulk packs etc.
- **Best-before dates** can be stored and printed for each item
- **Statistical function** for statistical analysis of series of measurements
- **User-friendly batch management** with batch master and batch number assignment, classification, batch derivation, batch determination, batch status management, shelf-life processing, documentary, original and WIP batches, batch-specific units of measurement, batch where-used list
- **Individual user settings can be stored**
  - User name and number
  - Password
  - Menu language
  - User profile
  - Additional guest mode for users without log-in
  - Authorisations etc.
- **Enormous database (1 GB)** for thousands of weighing results, items, recipes, recipe ingredients, container weights, user data etc.

- **Alibi memory:** paperless archive of weighing results, see also page 11
- **Electronic level indicator** continuously checks the position of the scale, sounds an alarm when the device is out of balance and gives visual instructions on how to correct the situation (only ILT-NM, -C)
- **High level of process reliability:** for define limit values for selected parameters, such as, e.g. temperature, levelling, minimum load, adjustment, etc. When the value falls outside these limits, a warning message will be issued and this can be stored with the measuring result
- **Individual print formats:** Printouts can be individually adjusted depending on operating mode, application or your own requirements, directly at the balance or the PC. In this way the data related to these processes is documented accurately, efficiently and clearly

## Technical data

- Weighing plate dimensions, stainless steel, WxD
 

























<b>A</b> 195x195 mm	<b>B</b> 230x230 mm
<b>C</b> 300x240 mm	<b>D</b> 347x259 mm
<b>E</b> 400x300 mm	<b>F</b> 500x400 mm
<b>G</b> 650x500 mm	
- Permissible ambient temperature 15 °C / 35 °C; 15 °C / 30 °C (verified)










## Accessories

- **Transponder card reader**, RFID technology, dimensions WxDxH 133x98x30 mm, for details see page 164, KERN KET-A05, **€ 450,-**
- **Transponder cards**, 10 pieces, for details see page 164, KERN KET-A08, **€ 65,-**

- Barcode scanner, hand-held version, dimensions WxDxH 152x84x63 mm, for details see page 163
- Version RS-232, KERN PET-A05, **€ 350,-**
- Version USB, KERN PET-A09, **€ 350,-**
- **USB keyboard** for easy capture of items, descriptions etc., dimensions WxDxH 440x128x24 mm, for details see page 164, KERN PET-A06, **€ 45,-**
- **Wall mount for display device**, dimensions WxDxH 135x148x110 mm, for details see page 164, KERN KET-A02, **€ 190,-**
- **Second display**, dimensions WxDxH 150x34x80 mm, for details see page 164, KERN KET-A03, **€ 210,-**
- **Large display**, stainless steel, digit height 111,7 mm, dimensions WxDxH 635x195x48 mm, details see page 163, KERN KET-A06, **€ 1450,-**
- **Analogue/Digital converter** to connect up to two platforms to the display device, for details see page 164, KERN KET-A01, **€ 350,-**
- **Direct thermal label printer**, inclusive software for easy editing of (adhesive) labels included, for details see page 163, KERN PET-A13, **€ 980,-**
- **Thermal transfer and direct thermal label printer**, included software for easy editing of (adhesive) labels, for details see page 163, KERN PET-A14, **€ 1000,-**
- **Software for database management**, for convenient administration of item data at the PC. For details see page 163, KERN KET-A04, **€ 300,-**
- **Suitable printers** and an extensive accessories range see page 157 ff.

## STANDARD

 CAL INT ILT-NM, -C	 CAL EXT ILT-BM, -GM	 MEMORY	 RS 232	 USB	 SWITCH	 LAN	 GLP PRINTER	 PCS	 RECIPE only ILT-NM, -C	 SUM only ILT-BM, -GM	 PERCENT	 UNIT	 TOL	 MOVE	 UNDER not ILT-BM, -GM	 230 V	 DMS ILT-BM, -GM	 FORCE ILT-NM	
 1 DAY ILT-BM, NM	 3 DAYS ILT-GM	 3 YEARS WARRANTY	 DAKKS +3 DAYS	 M +3 DAYS not ILT-C															

Model	Weighing range [Max] kg	Readout [d] g	Verification value [e] g	Minimum load [Min] g	Weighing plate	Price excl. of VAT ex works €	Optionen			
							Verification		DAkKS Calibr. Certificate	
							 KERN	€	DAkKS KERN	€
ILT 6K-3GM	3   6	1   2	1   2	40	B	1810,- <sup>Ⓣ</sup>	965-228 	55,-	963-128	88,-
ILT 6K-4BM	6	0,1	1	5	A	1950,-	965-217 	77,-	963-128	88,-
ILT 10K-3GM	6   15	2   5	2   5	40	C	1830,- <sup>Ⓣ</sup>	965-228 	55,-	963-128	88,-
ILT 10K-3LGM	6   15	2   5	2   5	40	E	1870,- <sup>Ⓣ</sup>	965-228 	55,-	963-128	88,-
ILT 10K-5NM	10	0,01	0,1	0,5	D	3600,- <sup>Ⓣ</sup>	965-217 	77,-	963-128	88,-
ILT 30K-2GM	15   30	5   10	5   10	200	E	1880,- <sup>Ⓣ</sup>	965-228 	55,-	963-128	88,-
ILT 60K-2GM	30   60	10   20	10   20	400	E	1880,- <sup>Ⓣ</sup>	965-229 	93,-	963-129	105,-
ILT 60K-2LGM	30   60	10   20	10   20	400	F	1930,- <sup>Ⓣ</sup>	965-229 	93,-	963-129	105,-
ILT 35K-4NM	35	0,1	1	5	D	4200,- <sup>Ⓣ</sup>	965-217 	77,-	963-128	88,-
ILT 50K-4C	50	0,1	-	-	D	5500,- <sup>Ⓣ</sup>	-	-	963-128	88,-
ILT 60K-3BM	60	1	10	50	F	2400,- <sup>Ⓣ</sup>	965-218 	110,-	963-129	105,-
ILT 100K-2GM	60   150	20   50	20   50	1000	F	1920,- <sup>Ⓣ</sup>	965-229 	93,-	963-129	105,-
ILT 100K-2LGM	60   150	20   50	20   50	1000	G	2120,- <sup>Ⓣ</sup>	965-229 	93,-	963-129	105,-
ILT 300K-2GM	150   300	50   100	50   100	2000	G	2120,- <sup>Ⓣ</sup>	965-229 	93,-	963-129	105,-

Dual-range balance switches automatically to the next largest weighing range [Max] and readout [d].

Note: For applications that require verification, please order verification at the same time, initial verification at a later date is not possible. Verification at the factory, we need to know the full address of the location of use.

<sup>Ⓣ</sup> Price reduction

For more information, please visit [www.kern-sohn.com/de/ILT](http://www.kern-sohn.com/de/ILT) · Order hotline +49 [0] 7433 9933-0