

COMBUSTIBLE GAS DETECTOR


With ultra-sensitive, long life sensor



Detects all hydrocarbon and other combustible gases including propane, methane, butane, industrial solvents and more.

Unit is preset at normal sensitivity, but you can switch to high or low. Slow beeping indicates that unit is warmed up. Frequency increases when a leak is detected until an alarm sounds when moving into high gas concentration. The Smart Alarm™ LED indicates leak size.

If no leak is detected in a suspected area, select high sensitivity. This will detect even low levels in the area. Move the tip over more defined areas, and you will be alerted when the tip encounters the concentration at the leak source.

- Ultra-sensitive sensor detects less than 15 ppm methane and better than 12 ppm for propane. Performs equally well on a complete list of detectable gases including acetylene, butane and isobutane
- Automatic calibration and zeroing
- Sensor replacable after full service life
- Smart Alarm LED shows how big or small a leak is on a scale of one to 9.
- 18-month limited warranty (12-month warranty on sensor)
- Made in USA 

APPLICATIONS:

- Internal gas lines/pipes
- Propane filling stations
- Gas heaters
- Combustion appliances
- Hydrocarbon refrigerant
- Heat exchangers
- Marine bilges
- Manholes
- Air quality
- Arson residue (accelerants)

Specifications

- Warm up time: 25 seconds
- Power battery: 4 AA alkaline batteries, 20 hours continuous life
- Probe length: 17" (43.17 cm)
- Sensor life: 500 hours
- Body length: 10.5" (26.67 cm)
- Weight: 16 oz. (0.45kg)
- Operating temperature range: 32° to 110°F (0° to 43°C)

UPC#	Description
69373	Combustible gas detector with case
69371	Replacement sensor
69387	Carrying case – blow molded
69379	Battery cover and screw (2003-2011)
69347	Battery cover and screw (2011)